

Assembly Instruction For 11268

Place the glass and cover on the socket, then secured by socket ring

