

## Assembly Instruction For 9052

- 1. Place the glass on the socket, then secured by metal cap and socket ring
- 2. The another 1PC as same the step 1

